





PicoLAS GmbH Burgstr. 2 52146 Würselen Germany

Phone:+49 (0) 2405-64594-60Fax:+49 (0) 2405-64594-61E-mail:info@picolas.deWeb:www.picolas.de

Table of Contents

LDP-V 80-100 V3.3	3
How to get started	4
How to connect the LDP-V 80-100	5
Operating Range Diagram	6
Maximum Duty Cycle vs. Output Current	8
Current Droop vs. Pulse Duration	8
Internal Structure of the LDP-V	8
How to use the internal HV-DC Supply	9
Pulse Output	
Trigger Input	11
Trigger Output Monitor	11
Absolute Maximum Ratings	12
Mechanical Details of the Baseplate	

PicoLAS FOCUSSING POWER TO THE POINT

LDP-V 80-100 V3.3

Driver Module for pulsed Lasers



Product Description

The LDP-V 80-100 is a small and inexpensive source for nanosecond pulses. The device is optimized for pulse repetition from single shot up to MHz repetition.

Its typical application is driving pulsed laser diodes. Those can be mounted directly onto the LDP-V, eliminating the need for strip lines. The diode must be electrically isolated from earth (chassis) ground. Compatible packages: TO-18, TO-5, TO-52, 5.6 mm, 9 mm and similar.

Despite its small size, the LDP-V is designed for ease of use. It eliminates the need for multiple peripheral supply units. A single 15 .. 24 V DC supply and a triggering signal are all which is required for ope

Add PLC with Do 15 tha

Rev. 1905

- Compact OEM module
- 5 to 80 A output current
- < 6 ns rise time
- Pulse width control via SMC trigger input $(12 \text{ ns to } 10 \text{ } \mu\text{s})$
- Rep. rates from single shot to 2 MHz
- Single +15 .. 24 V supply
- Current monitor and isolated monitor
- Applications: LIDAR, Measurements, Ignition, Rangefinding, Biochemistry, ...

Technical Data*

Output current	5 80 A
Max. output voltage	100 V
- int. high voltage	0 100 V, 1 A, 15 W
Rise time	Typ. 4 ns, max. 6 ns
Trigger delay	Typ. 36 ns. max. 40 ns
Min. pulse duration	12 ns
Max. pulse duration	< 1 µs (@ 80 A)**
Trigger range	Single shot to 2 MHz**
	(refer to diagram with
	operating limits)
Trigger input	5 V into 50 Ω via SMC-
	jack
Trigger output	Galvanically isolated
	Rogowski coil
Current monitor	40 A/V into 50 Ω
Supply voltage	1524 V, 2.2 A
20 50 50 ATU	Optional: 0 100 V, 30 W
	(external high voltage)
Max. power dissipation	25 W
Dimensions in mm	75 x 44 x 20
Weight	76 a
Operating temperature	-20 to +55 °C

* Measured into a short instead of laser diode. Technical data is subject to change without further notice.

** See manual for detailed information.

eration. ditionally, you can upgrad S-21 controller to enable h a PC or the external op not use PLCS-21 with hig V. If you use the PLCS-21 n 15 V the device will be	e the LDP-V with the USB 2.0 communication erating unit PLB-21. ther supply voltage than with higher voltage damaged.	Optional Accessories:	PLCS-21 PLB-21 LDP-V BOB LDP-V KIT	
LAS GmbH astr. 2	Phone: +49 (0)24	05 64594 60	E-mail:	sales@picolas.de

Pico Burg 52146 Würselen Germany

Fax: +49 (0)2405 64594 61 Web: www.picolas.de

How to get started

Step	What to do	Check
1	Unpack your device.	
2	Make a short at the output.	
3	Turn the high voltage to the lowest value (turn poti fully counterclockwise).	
4	Connect a pulse source with the desired pulse width to the selected triggering input.	E.g. 100 ns, 100 Hz repetition rate.
5	Connect your scope.	Select 50 Ohm termination, trig on neg. falling edge, 200 mV/div.
6	Apply the supply voltage. Security advice: Do not touch any leads of the output or the output capacitors as they are connected to a high voltage of up to 100 V.	Connect 15 24 V DC power supply to the pin header. See page 5 for details. Note : Some supplies have a voltage overshoot during turn on/ turn off. This may damage the device.
7	Adjust the value of the desired pulse current (turn the poti clockwise until the current reaches the desired level).	
8	Disconnect the supply, remove the short at the output and assemble the laser diode (polarity!).	
9	Reconnect the supply and check the optical output of your laser diode.	Note : The actual current is always some percent lower than the value of step 7. Adjust the current with help of the poti.

How to connect the LDP-V 80-100



Connections via Pin header:

Pin	Name	Description
1	GND	Ground return
2	HV+	External high voltage supply input (0 100 V) for connecting an alternative HV-DC supply. See page 9 for details.
3	GND	Ground return
4	+15 24 V	Supply voltage, connect to a power supply.
5*	Disable_Poti	Disables the internal HV setpoint poti when set high.
6	Pulse_In	Trigger input into 50 Ohm
7	Disable	Disables the driver when set high.
8*	U-Monitor	High voltage monitor output (scale: 40 mV/V) for supervising the actual high voltage.
9	NTC	Internal 10 kOhm NTC versus GND for temperature monitoring. (B-value: 3620)
10*	Ext_HV_Setpoint	External HV setpoint input (scale: 25 V/V) allows control over the internal HV-DC source.

*These pins had to be left unconnected in older versions then V3

Trigger Input:

The trigger input requires a signal level of 5 V and is terminated with 50 Ohm.

Current Monitor Output:

The current monitor output has a scale of 40 A/V with a negative signal output. It has a source impedance of 50 Ohm and must be terminated with 50 Ohm to achieve the correct scale.

Laser Diode Connection:

The laser diode can either be connected via the mounting holes on the top side of the pulser (inner hole: anode, outer hole: cathode) or at the rectangular pads on top (anode) and bottom (cathode) of the pulser.

Security Advice: Do not touch any leads of the output or the output capacitors as they are connected to a high voltage of up to 100 V.

Do not use PLCS-21 with higher supply voltage than 15 V. If you use the PLCS-21 with higher voltage than 15 V the device will be damaged.



Operating Range Diagram

LDP-V 80-100 V3: Max. Reprate vs. Pulsewidth (internal HV, without cooling)





LDP-V 80-100 V3: Max. Reprate vs. Pulsewidth (external HV, with cooling)

LDP-V 80-100 V3: Max. Reprate vs. Pulsewidth (external HV, without cooling)



Maximum Duty Cycle vs. Output Current

The following table shows the maximum allowable duty cycle depending on a given output current.

Output current	Max. duty cycle	Typical high	Max. duty cycle
in A	with ext. HV	voltage in V	with int. HV
5	1	7.66	0.784
10	0.2889	13.71	0.219
15	0.1284	19.77	0.101
20	0.0722	25.82	0.058
25	0.0462	31.88	0.038
30	0.0321	37.93	0.026
35	0.0236	43.99	0.019
40	0.0181	50.04	0.015
45	0.0143	56.10	0.012
50	0.0116	62.15	0.010
60	0.0080	74.26	0.007
70	0.0059	86.37	0.005
80	0.0045	98.48	0.004

With active cooling of the baseplate:

Current Droop vs. Pulse Duration

The following table shows the absolute output current droop (in A) versus pulse length. Pulse durations shorter than one microsecond are not considered as the droop is typically lower than 5 %.

	Pulse duration in µs		
Current in A	1	5	10
5	0.12	0.36	0.6
15	0.4	1.2	2.0
30	1.0	3.0	6.0
50	2.0	6.0	12.0
80	4.0	-	-

Internal Structure of the LDP-V

The LDP-V series generates the pulses by a simple but efficient principle. First, the storage capacitors (C_S) are charged, whether through the internal HV-DC supply or an external high voltage source. When a pulse is applied at the trigger input the high speed mosfet opens and the current flows from the capacitor through the laser diode, mosfet and current sense resistors. At the end of the pulse, the mosfet closes again and the current stops. The generated current depends on the applied high voltage, the laser diode compliance voltage and its differential resistance.

The following formula gives a good estimation of the laser diode current depending on the pulser's high voltage supply U_{HV} , the laser diode compliance voltage U_{comp} and its differential resistance R_{diff} :

$$I_{LD} \approx \frac{U_{HV} - U_{comp}}{1.1 + R_{diff}}$$

The laser diode current is measured with current sensing resistors (current monitor output) and with the galvanically isolated Rogowski coil. Disable and trigger input provide full control of the driver's pulsing capability to the user. The required DC high voltage can either be applied through an external voltage source or it can be generated with the integrated HV-DC supply. The internal supply is controlled by the HV setpoint poti or, when the Disable_Poti (pin 5) pin is set high, via the Ext_HV_setpoint (pin 10) pin. A voltage monitor (pin 8) provides feedback of the high DC voltage.

The Diode D_{RP} prevents the laser diode from reverse currents; a 10kR NTC provides the possibility to monitor the pulser temperature. An overtemperature protection is NOT integrated on the driver.



How to use the internal HV-DC Supply

The LDP-V series provides a high power (up to 15 W / 1 A / 100 V) internal high voltage supply. To adjust the laser diode current to the desired value follow the steps below. **Note:** Make sure that the solder junction is done to activate the HV-DC supply.

- 1. Turn the poti fully counterclockwise
- 2. Apply the 15 .. 24 V supply voltage
- 3. Start pulses
- 4. Measure the diode current
- 5. Adjust the level of the high voltage supply (hence the level of the current) by turning the poti clockwise

Since version 3 of the LDP-V series, the HV-DC supply can also be controlled through an external setpoint signal on pin 10 of the pin header (Ext_HV_Setpoint); the scale is 25V/V. To enable the external setpoint pin and disable the internal poti, pin 5 (Disable_Poti) of the pin header has to be set to "high". Otherwise the internal poti will override the external signal. The high DC voltage can be monitored at pin 8 (U-Monitor) with a scale of 40 mV/V.

Note: Older versions are not capable of these features and the above mentioned pins have to be left unconnected!

Security Advice:

Do not touch any leads of the output or the output capacitors as they are connected to a high voltage of up to 100 V.

Pulse Output

The LDP-V series provides ultra rapid pulse rise- and falltimes in the region of several nanoseconds. However, pulse rise and fall depend on the parasitic stray inductance of the cabling to the laser diode. Direct connection without any kind of wires to the module is absolutely necessary for best results. For detailed information about the effect of the laser diode connection on the pulse shape please refer to PicoLAS Application Notes "Impedance of Diodes" and "LD-Connections".



Typical Pulse Rise- and Falltimes of LDP-V 80-100 (scale: 10 A/Div)

Trigger Input

The trigger input, both on the pin header and the SMC jacket, is terminated with 50 Ohm to ground. The trigger source has to be able to provide a signal level of 5 V with a 50 Ohm load.

The delay between the triggering signal and the load current is very low around 36 ns and very constant. The pulse-to-pulse jitter is very stable below 1 ns if the supply voltage and temperature are kept constant.



Typical trigger delay of LDP-V 80-100

Trigger Output Monitor

The trigger output signal is generated with an integrated, isolated Rogowski coil and provides an ultra fast galvanically isolated signal. The signal shape is proportional to the derivative of the load current. It can be used for a current response triggering signal and has no delay to the load current. Combined with an integrator it is possible to use this signal for a galvanically isolated current monitor. The isolation barrier is suitable for voltages up to 100 V and prevents unwanted ground loops.



Absolute Maximum Ratings

Supply voltage range: 12 .. 26 V Max. voltage at HV pin: 100 V Max. output current U-monitor, NTC: 1 mA Input voltage range Disable_Poti, Ext_HV_Setpoint: 0 .. 5 V Input voltage range trigger input, disable: 0 .. 15 V Storage temperature: -20 .. +85 °C non condensing

Security Advice:

Do not touch any leads of the output or the output capacitors as they are connected to a high voltage of up to 100 V.

Mechanical Details of the Baseplate

All dimensions in millimetres.

